




A (x1) B (x2)


 M-A (x4) M6x14	 M-B (x4) M8x20	 M-C (x4) Ø15xØ8x5
 W-A (x3) ST6.3x55	 W-B (x3) Ø10x45	 W-C (x3) D6




1




2



3




✓ ✗ ✗




Ø4.5mm (Ø3/16")
55mm (2.2")


Ø10mm (Ø3/8")
60mm (2.4")




W-B W-C W-A

4






✗ ✓




M-A M-B M-C


5




2+



6



7



Note: If the display does not stop at your desired position, adjust the two side screws alternately using the tools as shown.